



**1**

## PREPARE AND ARRANGE THE BASE SUPPORTS

Peel the protective adhesive tape from the nine cylindrical base core supports and arrange them on the floor in a 3 × 3 grid. Ensure all supports are evenly aligned to form a stable base.

**2**

## FIX THE BOTTOM LID

Place the bottom lid over the arranged base supports. Press firmly so the lid securely bonds with all nine adhesive base cores.

**3**

## UNFOLD AND LOCK THE MAIN BIN BODY

Unfold the PARI E-Bin main structure and engage the locking flaps to form the central body. Ensure the bin stands upright and all edges are properly locked.

**4**

## PREPARE THE INNER COLLECTION CONTAINERS

Unfold the two inner collection containers, marked Left and Right. Secure the bottom of each container using tape to provide strength and stability.

**5**

## INSTALL THE INNER CONTAINERS

Place the inner containers inside the PARI E-Bin and align them with the left and right front openings. Fix them securely using the pre-attached Velcro strips on the inner walls.

**6**

## PLACE THE TOP LID AND SEAL

Position the top lid on the PARI E-Bin and press down firmly to seal it in place.  
The PARI E-Bin is now fully installed and ready for use.



**SCAN THE INSTALLATION  
QR CODE FOR A STEP-BY-STEP  
VIDEO AND SUPPORT.**